



KENWOOD "CA" KM080
KENWOOD COOKING CHEF





KENWOOD "CA" KM080

KM080 COOKING CHEF

Pos.	Code	Description
	KW710658	SPANNER
	KW630879	GREASE - FOOD GRADE - 100g TUBE
001	KW712887	MEDIUM/HIGH SPEED OUTLET COVER ASSEMBLY
002	KW674980	MEDIUM DRIVE OUTLET SPIGOT - GREY
003	KW714721	SPIGOT SEAT PLATE - PRINTED
004	KW712885	TOP COVER - PRINTED 'KENWOOD'
005	KW675001	FRONT GEARBOX MOUNT
006	KW712886	SLOW SPEED OUTLET COVER ASSEMBLY
007	KW712941	REED SWITCH ASSEMBLY COMPLETE (SLOW, MEDIUM & HIGH SPEED OUTLETS)
008	KW714722	INDUCTION PCB COVER
009	KW714706	FAN MOTOR ASSEMBLY
010	KW712948	LEAD ASSEMBLY (POWER PCB LCD PCB)
011	KW674552	MEDIUM SPEED DRIVE SHAFT & WASHER
013	KW712900	HEAD LIFT LEVER ASSEMBLY
014	KW712912	GEARBOX ASSEMBLY COMPLETE
015	KW712942	REED SWITCH ASSEMBLY (HEAT GUARD)
016	KW712894	TOP COVER SEAL
017	KW712892	LOWER GEARBOX COVER
018	KW712905	EXHAUST GRILLE - CHROME
019	KW712906	RETAINING SPRING (EXHAUST GRILLE)
021	KW712891	BUFFER - PACK 3 (SLOW SPEED OUTLET KNOB)
022	KW712890	SLOW SPEED OUTER KNOB ASSEMBLY INCLUDING BUFFER
023	KW714727	SUPPLY CORD ASSEMBLY - US/CA PLUG
024	KW714707	INDUCTION COIL AND NTC ASSEMBLY
025	KW712920	NTC AND BOWL REED SWITCH ASSEMBLY INCLUDING COVER
026	KW712911	FOOT (PACK 6)
027	KW712910	BASE MOULDING
028	KW714712	INDUCTION PCB ASSEMBLY
029	KW710366	HEADLIFT SPRING & LATCH PLATE. ATTENTION CHECK TECHNICAL INFORMATION IT0129
033	KW712946	LEAD ASSEMBLY (CONTROL PCB POWER PCB)
034	KW712944	EARTH LEAD ASSEMBLY (PEDESTAL)
035	KW714708	POWER PCB ASSEMBLY

KENWOOD "CA" KM080

KM080 COOKING CHEF

Pos.	Code	Description
036	KW712923	CARRIER (POWER PCB)
037	KW712904	PEDESTAL - PRINTED 'COOKING CHEF MAJOR'
038	KW675037	BODY LOCATION PIN
039	KW714718	BODY COVER
040	KW714719	BODY COVER INSERT
042	KW674746	GEARBOX TOP MOUNT
043	KW714717	BODY - WITH EARTH HOLE
044	KW712932	WAVY WASHER (TEMPERATURE CONTROL KNOB)
045	KW712931	TEMPERATURE CONTROL KNOB ASSEMBLY
046	KW712901	CIRCLIP (PACK 3) - HEAD LIFT LEVER
047	KW712954	SLOW SPEED OUTLET LEVER, PIN AND SPRING
049	KW714724	LCD PCB ASSEMBLY COMPLETE
050	KW712925	WAVY WASHER (SPEED CONTROL KNOB)
053	KW712924	SPEED CONTROL KNOB ASSEMBLY
054	KW712949	LEAD ASSEMBLY (CONTROL PCB LCD PCB)
055	KW712950	LEAD ASSEMBLY (HEAT GUARD / OUTLET COVER INTERLOCKS LCD PCB)
056	KW710743	MAGNET
057	KW712991	CONTROL PCB ASSEMBLY COMPLETE
058	KW712888	LATCH AND SPRING SET (MEDIUM/HIGH SPEED OUTLET COVER)
059	KW712907	HIGH TEMPERATURE SEAT PAD
060	KW712945	LEAD ASSEMBLY (INDUCTION PCB CONTROL PCB)
061	KW712908	INDUCTION COIL SUPPORT CASTING
062	KW714709	POWER LEAD ASSEMBLY (INDUCTION PCB POWER PCB)
063	KW674992	HIGH SPEED OUTLET SPIGOT - GREY
064	KW674655	GEARBOX LOCATION BOLT & WASHER (PACK 3)
066	KW712955	DOWEL TUBE AND MOUNT SET
067	KW712943	EARTH LEAD ASSEMBLY (GEARBOX)
068	KW674564	LARGE PULLEY *use stall plug (KW710409) to remove & refit pulley
069	KW712953	GEARBOX UPPER COVER - WITH EARTHING HOLE
072	KW674693	GEARBOX ASSEMBLY BOLT KIT
073	KW674617	PINION GEAR ASSEMBLY
074	KW674681	IDLER GEAR ASSEMBLY & WASHERS

KENWOOD "CA" KM080

KM080 COOKING CHEF

Pos.	Code	Description
075	KW710409	STALL PLUG *special tool to assist with the removal & replacement of large pulley
076	KW674605	PENULTIMATE GEAR ASSEMBLY & WASHERS
077	KW712893	GEARBOX REAR SPACER
078	KW674590	OUTPUT SHAFT GEAR ASSEMBLY
079	KW710368	VERTICAL DRIVE SHAFT ASSEMBLY - MAJOR
080	KW710369	GEARBOX LOWER COVER ASSEMBLY
082	KW712913	PLANET HUB ASSEMBLY INCLUDING COVER, SEAL AND HUB NUT
084	KW712914	PLANET HUB SEAL
085	KW712915	PLANET HUB COVER
086	KW712916	PLANET HUB NUT
087	KW712875	HIGH TEMPERATURE SPATULA
088	KW714713	SPLASHGUARD ASSEMBLY COMPLETE
089	KW714714	LID (SPLASHGUARD)
090	KW712868	FLEXIBLE WIPER
093	KW713240	CLEANING BRUSH (for flexible wiper)
094	KW712867	HIGH TEMPERATURE FLEXIBLE BEATER
095	KW712266	WHISK
096	KW713836	STIRRING TOOL ASSEMBLY (modified)
097	KW712870	BEARING (STIRRING TOOL)
098	KW712871	WASHER
099	KW710878	MAJOR BEATER SHAFT ASSEMBLY
100	KW712903	GROMMET (QUADRANT) - PACK 3
103	KW712902	QUADRANT ASSEMBLY AND BRACKET
104	KW714710	MOTOR ASSEMBLY COMPLETE - 120V
105	KW713177	PULLEY
106	KW674722	DRIVE BELT
107	KW710367	MOTOR MOUNT MOULDING
108	KW674801	PLASTIC WASHER - PACK 3 *fits motor pulley
109	KW712884	FOLDING HANDLE - SINGLE - LEFT/RIGHT HAND SIDE
110	KW714716	SUPPORTING RING
112	KW714715	STEAMER BASKET ASSEMBLY COMPLETE

KENWOOD "CA" KM080

KM080 COOKING CHEF

Pos.	Code	Description
113	KW712883	REMOVEABLE TRAY
114	KW713966	BOWL ASSEMBLY - STAINLESS STEEL WITH HANDLES
115	KW712876	SCRAPER
116	KW712873	BOWL MAGNET ASSEMBLY AND CIRCLIP
117	KW713360	HEAT GUARD SEAL
118	KW714720	HEAT GUARD ASSEMBLY WITH SPRING RETAINER
119	KW712898	HINGE PIN
120	KW712899	HEAD LIFT SPRING
121	KW714837	DOUGH HOOK ASSEMBLY - WINGED - STAINLESS STEEL
122	KW711977	K BEATER ASSEMBLY - STAINLESS STEEL
127	KW712874	WORKSURFACE PROTECTION MAT
..		
..		
..		
..		
..		

KENWOOD
CA KM080
KM080 COOKING CHEF - 120V

Pos.	Code	Description
	KW714716	SUPPORTING RING
N/I	KW713926	MOTOR RETAINING SCREW TX20 - PACK 3
	KW714714	LID (SPLASHGUARD)
N/I	KW630879	GREASE - FOOD GRADE - 100g
001	KW712887	MEDIUM/HIGH SPEED OUTLET COVER ASSEMBLY
002	KW674980	MEDIUM DRIVE OUTLET SPIGOT - GREY
003	KW714721	SPIGOT SEAT PLATE - PRINTED
004	KW712885	TOP COVER - PRINTED 'KENWOOD'
005	KW675001	FRONT GEARBOX MOUNT
006	KW712886	SLOW SPEED OUTLET COVER ASSEMBLY
007	KW712941	REED SWITCH ASSEMBLY COMPLETE (SLOW
008	KW714722	INDUCTION PCB COVER
009	KW712918	FAN MOTOR ASSEMBLY
010	KW712948	LEAD ASSEMBLY (POWER PCB LCD PCB)
011	KW674552	MEDIUM SPEED DRIVE SHAFT & WASHER
013	KW712900	HEAD LIFT LEVER ASSEMBLY
014	IT0314	VEDI INFOTECNICA
014	KW715261	COMPLETE GEARBOX *13T04
015	KW712942	REED SWITCH ASSEMBLY (HEAT GUARD)
016	KW712894	TOP COVER SEAL
017	KW712892	LOWER GEARBOX COVER
018	KW712905	EXHAUST GRILLE - CHROME
019	KW712906	RETAINING SPRING (EXHAUST GRILLE)
021	KW712891	BUFFER - PACK 3 (SLOW SPEED OUTLET KNOB)
022	KW712890	SLOW SPEED OUTER KNOB ASSEMBLY INCLUDING BUFFER
023	KW714727	SUPPLY CORD ASSEMBLY - US/CA PLUG
024	KW714707	INDUCTION COIL AND NTC ASSEMBLY
025	KW712920	NTC AND BOWL REED SWITCH ASSEMBLY INCLUDING COVER
026	KW712911	FOOT (PACK 6)
027	KW712910	BASE MOULDING
028	KW714712	INDUCTION PCB ASSEMBLY
029	KW710366	HEADLIFT SPRING & LATCH PLATE
033	KW712946	LEAD ASSEMBLY (CONTROL PCB POWER PCB)
035	KW714708	POWER PCB ASSEMBLY
036	KW712923	CARRIER (POWER PCB)

KENWOOD
CA KM080
KM080 COOKING CHEF - 120V

037	KW712904	PEDESTAL - PRINTED 'COOKING CHEF MAJOR'
038	KW675037	BODY LOCATION PIN
039	KW714718	BODY COVER
040	KW714719	BODY COVER INSERT
042	KW674746	GEARBOX TOP MOUNT
043	KW712895	BODY - WITH EARTH HOLE
044	KW712932	WAVY WASHER (TEMPERATURE CONTROL KNOB)
045	KW712931	TEMPERATURE CONTROL KNOB ASSEMBLY
046	KW712901	CIRCLIP (PACK 3) - HEAD LIFT LEVER
047	KW712954	SLOW SPEED OUTLET LEVER
049	KW714724	LCD PCB ASSEMBLY COMPLETE
050	KW712925	WAVY WASHER (SPEED CONTROL KNOB)
053	KW712924	SPEED CONTROL KNOB ASSEMBLY
054	KW712949	LEAD ASSEMBLY (CONTROL PCB LCD PCB)
055	KW712950	LEAD ASSEMBLY (HEAT GUARD / OUTLET COVER INTERLOCKS LCD PCB)
056	KW710743	MAGNET
057	KW712991	CONTROL PCB ASSEMBLY COMPLETE
058	KW712888	LATCH AND SPRING SET (MEDIUM/HIGH SPEED OUTLET COVER)
059	KW712907	HIGH TEMPERATURE SEAT PAD
060	KW712945	LEAD ASSEMBLY (INDUCTION PCB CONTROL PCB)
061	KW712908	INDUCTION COIL SUPPORT CASTING
062	KW714709	POWER LEAD ASSEMBLY (INDUCTION PCB POWER PCB)
063	KW674992	HIGH SPEED OUTLET SPIGOT - GREY
064	KW674655	GEARBOX LOCATION BOLT & WASHER (PACK 3)
066	KW712955	DOWEL TUBE AND MOUNT SET
067	KW712943	EARTH LEAD ASSEMBLY (GEARBOX)
068	KW674564	LARGE PULLEY
069	KW712953	GEARBOX UPPER COVER - WITH EARTHING HOLE
072	KW674693	GEARBOX ASSEMBLY BOLT KIT
073	KW674617	PINION GEAR ASSEMBLY
074	KW674681	IDLER GEAR ASSEMBLY & WASHERS
075	KW710409	STALL PLUG *special tool to assist with the removal & replacement of large pulley
076	KW674605	PENULTIMATE GEAR ASSEMBLY & WASHERS
077	KW712893	GEARBOX REAR SPACER
078	KW674590	OUTPUT SHAFT GEAR ASSEMBLY

KENWOOD
CA KM080
KM080 COOKING CHEF - 120V

079	IT0313/UK0025	VEDI INFOTECNICA
079	KW715267	VERTICAL DRIVE SHAFT *13T04
080	KW710369	GEARBOX LOWER COVER ASSEMBLY
082	KW715268	HUB COVER
082	KW715266	PLANET HUB *13T04 - SEE TECHNICAL INFORMATION IT0314
082	KW712913	PLANET HUB ASSEMBLY INCLUDING COVER
084	KW712914	PLANET HUB SEAL - SEE TECHNICAL INFORMATION IT0314
085	KW712915	PLANET HUB COVER - SEE TECHNICAL INFORMATION IT0314
086	KW712916	PLANET HUB NUT - SEE TECHNICAL INFORMATION IT0314
088	KW714713	SPLASHGUARD ASSEMBLY COMPLETE
090	KW712868	FLEXIBLE WIPER
093	KW713240	CLEANING BRUSH (for flexible wiper)
096	KW714837	DOUGH HOOK - WINGED - STAINLESS STEEL
097	KW712870	BEARING (STIRRING TOOL)
098	KW712871	WASHER
100	KW712903	GROMMET (QUADRANT) - PACK 3
103	KW712902	QUADRANT ASSEMBLY AND BRACKET
104	KW714710	MOTOR - 120V
105	KW713177	PULLEY (ANKARSRUM MOTOR)
106	KW674722	DRIVE BELT
107	KW710367	MOTOR MOUNT MOULDING (ANKARSRUM MOTOR)
108	KW674801	PLASTIC WASHER - PACK 3
109	KW712884	FOLDING HANDLE - SINGLE - LEFT/RIGHT HAND SIDE
113	KW712883	REMOVEABLE TRAY
114	AW37575001	BOWL ASSEMBLY - STAINLESS STEEL WITH HANDLES
115	KW712876	SCRAPER
116	KW712873	BOWL MAGNET ASSEMBLY AND CIRCLIP
117	KW713360	HEAT GUARD SEAL (FOR MODIFIED HEAT GUARD)
118	KW714720	HEAT GUARD ASSEMBLY WITH SPRING RETAINER
119	KW712898	HINGE PIN
120	KW712899	HEAD LIFT SPRING
127	KW712874	WORKSURFACE PROTECTION MAT